Lens

Side Switch

ON ◀ ▶ OFF

Status LED

MicroSD Card Slot

PRISM TUBE

SD Card Format Button

DC Power Charging & Firmware Upgrade Port

Fault Reset
Pin-Hole Button