

Instructions for 44813 Lock Installation

TOP LINE / MID LINE / CLASSIC / KROME hatches

The Nuova Rade TOP LINE / MID LINE / CLASSIC / KROME hatches of can become lockable by having the 44813 lock installed in the handle cavity, as shown in Picture 1.

To make this conversion, you will need:

- the TOP LINE / MID LINE / CLASSIC / KROME hatch
- one Nuova Rade 44813 lock (Picture 2)
- Ø12mm drill
- Silicone (without benzene, acetone etc)



Picture 1:
Lock 44813 installed



Picture 2:
44813 Lock and Keys for Hatch



Picture 3:
"OPEN" Latch position
and drilling point (red dot)



Picture 4:
"CLOSED" Latch position.
(The blue dot is the lock pin passing
through the latch hole).

Instructions:

1. Place the hatch lid facing backside up.
2. Turn the latch as shown in Picture 3.
3. Find the drilling point, indicated on the hatch with a dimple (also marked in red in Picture 3).
4. Drill a Ø12mm hole.
5. Screw the 44813 lock into the hole drilled and seal it with silicone, to make it watertight.
6. Leave the silicone to dry.
7. To lock the hatch:
Bring latch to "closed" position (picture 4) and push the lock button.