


SHAD

KEEWAY CITY BLADE 125i '15

KIT TOP KOCT15ST



1 261861 x1



2 261042 x2
Ø16 Ø9 x 15



3 303017 x2
Ø6



4 302021 x2
M6



5 304225 x2
M6 x 45
Din 7991



6 261460 x2
Ø18 Ø11 x 45



7 303020 x2
Ø8



8 304173 x2
M8 x 75
Din 7380

! WARNING!

GB

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

E

No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

D

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

I

Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

F

Ne pas serrer les vis avant d'être sûr que le KIT est correctement monté et ajusté.

