


CROSSKIX ARE MADE TO HAVE A "RELAXED FIT"

They are made to have a little extra room but still has a secure fit that allows your feet to feel stable as you walk. There will be a slight amount of room around the perimeter of the foot and the sides of your feet may meet the shoe walls.

This holds true especially when you wear socks.



ADULTS

US (mens)	US (womens)	UK (mens)	UK (womens)	EU
3	5	3	2.5	35
4	6	4	3.5	36.5
5	7	5.5	5	38
6	8	6.5	6	39
7	9	7	6.5	40
8	10	7.5	7	41
9	11	8.5	8	42
10	12	9.5	9	43
11	13	10.5	10	44
12	14	11.5	11	45
13	15	12.5	12	46

KIDS

(boys./girls)

US	UK	EU
7	6	23
8	7	24
9	8	25
10	9	26
11	10	27
12	11	28
13	12	29
1	13	32
2	1	33