

HELMET

FITTING

1

FIND THE RIGHT SIZE

Measure your head circumference with a tape measure which you apply above your ears. You will find the correct helmet size for your head circumference in the table below.



2

PUTTING ON THE HELMET AND ADJUSTING THE CHIN STRAPS

The helmet shall sit tightly on your head directly above your eyebrows. Adjust the two chin straps so that they solidly fix and hold the helmet.



3

CHECK FIT WITH GOGGLES

In order to check the perfect fit of the helmet, please put on your goggles. There should be no gap at all or an only small gap between the upper edge of your goggles and the helmet.



SIZES AND HEAD CIRCUMFERENCE

Model	Size (cm)	XS	S	M	L	XL	XXL
STIVOT RACE		52-53	54-55	56-57	58-59	60-61	62-63
STIVOT RACE YOUTH		52-53	54-55	56-57	58-59		
SLALOM RACING CHINGUARD for helmet size		XS/S	XS/S	M/L	M/L	XL/XXL	XL/XXL

Model	Size (cm)	XXS	XS/S	M/L	XL/XXL
CREST, ALPHA, AGENT, SENSOR, BEACON, REBEL, STIVOT SL, VENTOR PRO R, VENTOR R			52-55	56-59	60-63
CARMA, ADORE, AVRIL, GRACE, CLOE, STIVOT YOUTH SL			52-55	56-59	
AI R YOUTH, VENTOR YOUTH R		49-51	52-55	56-59	
RENTAL SR			52-55	56-58	59-64
RENTAL JR		48-51	52-55	56-58	

Model	Size (cm)	XXS/XS	S/M
JOKER, STAR		49-52	53-56