


# HELMETS



- Ensure the helmet is a comfortable fit, not too tight where it causes pressure on any part of the head and not too loose where it can move around on the head under normal movement.
- Ensure the helmet is positioned correctly on the head as indicated above. Not too far back where it exposes the forehead and not too far forwards where it exposes the rear of the head and obstructs vision.
- Always ensure the straps are secure and positioned snugly below the chin but without restricting breathing. Ensure the buckle is fastened while using the helmet.

**A - Head.** Using a material measuring tape, measure the circumference of the head as indicated above. This should be the widest circumference of the head, usually around where the forehead and back of head protrude the most.

PRODUCT NAME	MEASUREMENT	XXS/XS	S/M	L/XL	S/XL	XL/XXL	S
Junior Elite 2.0 Helmet	A	49-52	-	-	-	-	-
Elite 2.0 Helmet	A	-	53-56	57-59	-	-	-
Junior Ultralite In-Mold	A	49-52	-	-	-	-	-
Ultralite In-Mold Helmet	A	-	53-56	57-59	-	-	-
Urbanlite Helmet	A	-	-	-	54-58	-	-
Pathfinder Helmet	A	-	-	-	54-58	58-61	-
Elite Helmet	A	-	-	-	-	-	54-55
Elite Icon Helmet	A	-	-	-	-	-	54-55