



## Bark'n Boot Liners™

# SIZING

	XXS / XS	S / M	L / XL
Bark'n Boots Size Range	2.0-2.25 in 51-57 mm	2.5-2.75 in 64-70 mm	3.0-3.25 in 76-83 mm



### Paw Width

Measurement  
across widest  
part of paw when  
bearing weight

### GETTING THE RIGHT SIZE FOR YOUR DOG

1. Have your dog stand on a firm surface.
2. Place a piece of paper under a front paw.
3. Lift dog's opposite front paw so that weight is placed firmly onto the paw being measured.
4. Mark BOTH SIDES of weighted paw at its widest point on the sheet of paper.
5. Measure that distance and choose correct boot size from the figures above. If you are between sizes, choose the smaller size.