

Skechers Men's Shoe Sizes

EU	USA	UK	CM
EU 39	6.5	5.5	24.5
EU 40	7.5	6.5	25.5
EU 41	8	7	26.0
EU 42	8.5	7.5	26.5
EU 42 1/2	9	8	27.0
EU 43	9.5	8.5	27.5
EU 43 1/2	10	9	28.0
EU 44	10.5	9.5	28.5
EU 44 1/2	11	10	29.0
EU 45	11.5	10.5	29.5
EU 45 1/2	12	11	30.0
EU 46	12.5	11	30.5
EU 47	13	12	31.0
EU 48	14	13	32.0
EU 49 1/2	15	14	33.0
EU 50 1/2	16	15	34.0

Styles marked with EWW are part of our Extra Wide Fit Collection.

Skechers Men's Wide Fit is equivalent to Men's 2E / 3E sizes.

Skechers Performance running and walking footwear sizes may vary

Skechers Women's Shoe Sizes

EU	USA	UK	CM
EU 35	5	2	22.0
EU 35 1/2	5.5	2.5	22.5
EU 36	6	3	23.0
EU 36 1/2	6.5	3.5	23.5
EU 37	7	4	24.0
EU 37 1/2	7.5	4.5	24.5
EU 38	8	5	25.0
EU 38 1/2	8.5	5.5	25.5
EU 39	9	6	26.0
EU 39 1/2	9.5	6.5	26.5
EU 40	10	7	27.0
EU 40 1/2	10.5	7.5	27.5
EU 41	11	8	28.0
EU 42	12	9	29.0
EU 43	13	10	30.0

Styles marked with EWW are part of our Extra Wide Fit Collection.

Skechers Women's Wide Fit is equivalent to Women's W or D width.

Skechers Performance running and walking footwear sizes may vary