

# WOMEN FOOTWEAR

## SKECHERS SIZE CHART

### WOMEN

USA	UK	EU	cm
5	-	35	22
5.5	-	35.5	22 1/2
6	3	36	23
6.5	3.5	36.5	23 1/2
7	4	37	24
7.5	4.5	37.5	24 1/2
8	5	38	25
8.5	5.5	38.5	25 1/2
9	6	39	26
9.5	6.5	39.5	26 1/2
10	7	40	27
10.5	7.5	40.5	27.5
11	8	41	28
12	9	42	29
13	10	43	30

ALL SIZES SHOWN ARE UK SIZES. Styles marked with EW are part of our Wide Width Collection.

SKECHERS Women's EW is equivalent to Women's W or D sizes.

Skechers Performance running and walking footwear sizes may vary.