

## **SIZING CHART** **VIBRAM® FUROSHIKI**

<b>WOMEN'S</b>			<b>MEN'S</b>		
VFF SIZE	WOMEN'S SIZE	FUROSHIKI SIZE	VFF SIZE	MEN'S SIZE	FUROSHIKI SIZE
36-37	5.5-6.5	<b>XS</b>	36-37	--	<b>XS</b>
38-39	7-8	<b>S</b>	38-39	5-6.5	<b>S</b>
40-41	8.5-9.5	<b>M</b>	40-41	7-8.5	<b>M</b>
42-43	10-11.5	<b>L</b>	42-43	9-10	<b>L</b>
44-45	12-13	<b>XL</b>	44-45	10.5-11.5	<b>XL</b>
46-47	--	<b>XXL</b>	46-47	12-13	<b>XXL</b>

Like snowflakes, every foot is unique and different. There is no guarantee that what we suggest is going to work with every foot.

