


DISPLAYS AND BUTTONS



C) SETTING THE DATE

1. Pull the crown out to the 1st position.

2. Turn the crown clockwise to set the date.

You can not adjust the date between approximately 9pm and 0:30am.

*After setting the time/date/day of the week, please push the Crown back to it's normal position before using.