EXPLODED VIEW AND PARTS LIST






Samsung is not liable for any damage to the product, any injury or any other product safety issue caused by any attempt to repair the product which does not carefully follow these repair and maintenance instructions or carried out by a non-authorized service provider, self-repair or non-professional repair of the product, Any damage to the product caused by an attempt to repair the product by any person other than a Samsung certified service provider will not be covered by the warranty.


Web site of Store(components, tools): www.samsung.com/support/

1. ASSY DOOR



Drawing No.	Model Code	Parts Code	Description	Remark
	WW7*T3***B*	DC81-01514A	ASSY-DOOR	BLACK
	WW8*T3***B*			
	WW9*T3***B*			
I	WW7*T3***W*	DC81-01545A	ASSY-DOOR	White
	WW8*T3***W*			
	WW9*T3***W*			
2	ALL MODELS	DC81-01477A	SWITCH DOOR LOCK	


2. ASSY DIAPHRAGM



This document can not be used without Samsung's authorization.


Drawing No.	Model Code	Parts Code	Description	Remark
1	ALL MODELS	DC81-01474A	ASSY-WIRE DIAPHRAGM	
2	ALL MODELS	DC81-01582A	DOOR DIAPHRAGM	
3	ALL MODELS	DC81-01458A	ASSY-CLAMP DIAPHRAGM	

3. ASSY DRAWER




Drawing No.	Model Code	Parts Code	Description	Remark
	WW7*T3****W	DC81-01519A	ASSY-DRAWER	White
	WW8*T3***W			
0	WW9*T3***W			
0	WW7*T3****S	DC81-01554A	ASSY-DRAWER	Silver
	WW8*T3****S			
	WW9*T3****S			
	WW7*T3****W	DC81-01520A	PANEL DRAWER	White
1	WW8*T3****W			
	WW9*T3***W			
1	WW7*T3****S	DC81-01555A	PANEL DRAWER	Silver
	WW8*T3****S			
	WW9*T3****S			
2	ALL MODELS	DC81-01493A	BODY DRAWER	
3	ALL MODELS	DC81-01492A	CAP RINSE	

4. ASSY HOUSING DRAWER



Drawing No.	Model Code	Parts Code	Description	Remark
	WW80T301MBS/EF			
	WW80T301MBW/EF			
	WW80T301MBW/LE			
	WW80T301MWW/EC			
	WW80T301MWW/EF			
	WW80T301MWW/ET			
	WW80T301MWW/LE			
	WW80T304MBS/EF	DC82-01288A	ASSY-HOUSING DRAWER	
	WW80T304MBS/LE			
	WW80T304MBW/EF			
	WW80T304MBW/EO			
	WW80T304MBW/LE			
	WW80T304MWW/EC			
	WW80T304MWW/EE			
	WW80T304MWW/EF			
	WW80T304MWW/ET			
	WW80T304MWW/EU			
	WW80T304MWW/LE			
	WW80T304MWW/WS		ASSY-HOUSING DRAWER	
	WW80T304PWW/EG	DC82-01288A		
	WW81T301MWW/LE			
	WW81T304MWW/LE			
	WW81T304PWW/EG			
	WW8ET304PWW/EG			
0	WW70T301MBW/LE	DC82-01286A		
	WW70T301MWW/EF		ASSY-HOUSING DRAWER	
	WW70T301MWW/LE			
	WW70T302MBS/LE			
	WW70T302MBW/EO			
	WW70T302MWW/EO			
	WW70T302MWW/ET			
	WW70T303MBS/EF			
	WW70T303MBW/EF			
	WW70T303MWW/EF			
	WW70T304MBW/EO			
	WW70T304MWW/EO			
	WW71T301MWW/LE			
	WW90T304MBW/EE	DC82-01284A	ASSY-HOUSING DRAWER	
	WW90T304MBW/E0			
	WW90T304MBW/LE			
	WW90T304MWW/EE			
	WW90T304MWW/EF			
	WW90T304MWW/EO			
	WW90T304MWW/EP			
	WW90T304MWW/EU			
	WW90T304MWW/LE			
	WW90T304PWW/EG			
	WW91T304MBW/LE			
	WW9FT304PWW/EG			
1	ALL MODELS	DC81-01487A	ASSY-S.HOUSING DRAWER	
2	ALL MODELS	DC81-01486A	HOUSING DRAWER-LOW	

5. ASSY FILTER



Drawing No.	Model Code	Parts Code	Description	Remark
1	ALL MODELS	DC81-01447A	ASSY-FILTER	