Thanks for purchasing a Swim Secure™ open water swimming product!

Please read this important information regarding your tow-float or dry bag:

Videos of the products in use are available at **www.swimsecure.co.uk**

The Swim Secure™ tow-float causes little drag when in use. Please be aware that carrying heavy kit (eg. hiking boots) in the dry bag could create drag, especially if you are a fast swimmer. This does not affect slower paced swimmers as much.

Please note that incorrectly sealing the dry bag or damaging the bag may cause leaking.

Use the back of the valve cap to deflate your float.

NOTES FOR TOW-DONUTS

Step 1
Inflate top valve

Step 2
Insert items

Step 3
Seal bag

Step 4
Inflate bottom valve



TOW-FLOAT INSTRUCTIONS



Step 1
Inflate both sides of the float equally.

Step 2
Loop the leash through the plastic handle. The leash can now permanently stay in this position.



Step 3
Pass the belt through the loop of the leash (this can now stay around the belt).



Step 4
Adjust the belt so it fits snugly around your waist.

Please note: the fastening may be stiff the first few times you use it.

DRY-BAG INSTRUCTIONS

Step 5
Stuff your equipment as far as possible into your dry bag. Take care not to have sharp objects in or next to the bag.



Step 6
Squeeze the air out of the bag and roll the bag down to the arrow section indicated on the bag.



Step 7
Fasten the bag by clipping the plastic buckle together. Use the plastic loop to provide an extra secure knot.



Step 8
Inflate your bag by blowing air into the two chambers equally.



Step 9
You can now attach the belt around your waist. Please note: the fastening may be stiff the first few times you use it.



Step 10
Enjoy your swim!

IMPORTANT:
THIS PRODUCT SHOULD ONLY BE USED BY COMPETENT SWIMMERS; IT IS NOT A BUOYANCY AID AND DOES NOT GIVE ANY BUOYANCY. THE TOW-FLOAT FLOATS BEHIND THE SWIMMER ON A SHORT LEASH.