

MTB HOPPER

USER MANUAL




Always

wear your helmet.
It is recommended to wear knee pads, gloves and other safety equipment.



Momentum speed for beginners:
12 km/h – 20 km/h
(7 mph – 12 mph).
Feels similar to your running speed.



Keep the **handlebars straight** while riding onto the kicker and in the air. Approach the kicker in a straight line. **Do not brake** on the kicker. Jump once you feel confident about it.



Before the jump, ensure that **ramp is standing firmly** on the surface. If the surface is uneven, **adjust** the legs.

Body position:

1. Stop pedaling ~6 meters before the kicker and stand on your pedals. The crank arms should be parallel to the ground.
2. Keep your hips above the axis of the rear wheel.
3. Lean your torso forward.
4. Slightly bend your elbows.
5. Keep your head straight, look forward and not under your wheels.
6. Before the jump, lower your seat as much as possible.



The kicker is designed for **MTB and BMX** bikes.



MTB HOPPER is designed for longevity, to withstand any weather and provide good grip with tires. We recommend to store it in a **dry place**.

Use it responsibly.
Go through all the steps before riding to ensure safety. If you have the opportunity, train together with more experienced riders. Good luck at improving your riding skills!

HOPPER PRO WHEELS ATTACHMENT



Please send us your first jump photo or video and we will share it on our Facebook!
info@mtbhopper.com



Celebrate your personal victories anywhere!

HOPPER PRO RAMP ASSEMBLY

