
SKIP*HOP.

activity gym



EN Please retain this information for future reference.

ASSEMBLY:

- Place mat on floor with pattern facing up. Slide lower arch through fabric loop on upper arch and secure with hook-and-loop closure. Position on mat with fabric loop facing down (A).
- 2. Select any plastic hook (at ends of each arch) and insert into the nearest slot on mat (B).
- 3. Reach under mat and put the hook through the fabric loop on the bottom of the mat (C).
- Repeat on opposite side of the mat to complete one arch, then twist arches into "X" and repeat with second arch.

Requires assembly by an adult.